

Coast Guard, DHS

§ 117.287

§ 117.272 Boot Key Harbor.

The draw of the Boot Key Harbor drawbridge, mile 0.13, between Marathon and Boot Key, will open as necessary on the hour between the hours of 7 a.m. to 7 p.m. At all other times, the bridge will open following a one hour notification to the bridge tender by calling the posted cell phone number. The draw shall open on demand and as soon as practicable for the passage of tugs with tows, public vessels of the United States and vessels whereby a delay would endanger life or property.

[CGD07-05-063, 71 FR 14806, Mar. 24, 2006]

§ 117.273 Canaveral Barge Canal.

(a) The drawspan of the Christa McAuliffe Drawbridge, SR 3, mile 1.0, across the Canaveral Barge Canal need only open daily for vessel traffic on the hour and half-hour from 6 a.m. to 10 p.m.; except that from 6:15 a.m. to 8:15 a.m. and from 3:10 p.m. to 5:59 p.m., Monday through Friday, except Federal holidays, the drawspan need not open. From 10:01 p.m. to 5:59 a.m., everyday, the drawspan must open on signal if at least 3 hours notice is given to the drawtender. The drawspan must open as soon as possible for the passage of public vessels of the United States and tugs with tows.

(b) The drawspan of the SR401 Drawbridge, mile 5.5 at Port Canaveral, must open on signal; except that, from 6:30 a.m. to 8 a.m. and 3:30 p.m. to 5:15 p.m. Monday through Friday except Federal holidays, the drawspan need not be opened for the passage of vessels. From 10 p.m. to 6 a.m., the drawspan must open on signal if at least three hours notice is given. The drawspan must open as soon as possible for the passage of public vessels of the United States and tugs with tows.

[USCG-2001-10881, 71 FR 70310, Dec. 4, 2006]

§ 117.279 Coffeepot Bayou.

The draw of the Snell Isle Boulevard bridge, mile 0.4 at St. Petersburg, need not be opened for the passage of vessels.

§ 117.283 Dunns Creek.

The draw of the US17 bridge, mile 0.9 near Satsuma, shall open on signal if at least three hours notice is given.

§ 117.285 Grand Canal.

(a) The draw of the Lansing Island bridge, mile 0.7, shall open on signal, except that during the evening hours from 10 p.m. to 6 a.m. from Sunday evening until Friday morning, except on evenings preceding a Federal holiday, the draw shall open on signal if at least 2 hours notice is given.

(b) The draw of the Tortoise Island bridge, mile 2.6, shall open on signal; except that from 10 p.m. to 6 a.m. from Sunday evening through Friday morning, the draw shall open on signal if at least 2 hours advance notice is given. From 10 p.m. to 6 a.m. on Friday and Saturday and on evenings immediately preceding Federal holidays, the draw shall open on signal if at least 30 minutes advance notice is given.

[CGD7-92-113, 58 FR 31474, June 3, 1993, as amended by CGD07-98-048, 64 FR 30391, June 8, 1999]

§ 117.287 Gulf Intracoastal Waterway.

(a) Public vessels of the United States and tugs with tows must be passed through the drawspan of each drawbridge listed in this section at anytime.

(a-1) The draw of the Boca Grande Swingbridge, mile 34.3, shall open on signal; except that, from 7 a.m. to 6 p.m., Monday through Friday, except Federal holidays, the draw need open only on the hour and half hour. On Saturday, Sunday and Federal holidays, from 7 a.m. to 6 p.m., the draw need open only on the hour, quarter hour, half hour and three quarter hour.

(a-2) The draw of the Venice Avenue bridge, mile 56.6 at Venice, shall open on signal, except that from 7 a.m. to 4:30 p.m., Monday through Friday except Federal holidays, the draw need open only at 10 minutes after the hour, 30 minutes after the hour and 50 minutes after the hour and except between 4:35 p.m. and 5:35 p.m. when the draw need not open.

(b) The draw of the Hatchett Creek (US-41) bridge, mile 56.9 at Venice, shall open on signal, except that, from